




Lubriplate Lubricants Company

146 Years of Continuous Lubrication Innovation



CONVERTING HYDRAULIC SYSTEMS FROM WATER GLYCOL TO SYNXTREME FRH1-46 FLUIDS

- 1) Completely drain and clean the reservoir, while the old fluid is warm.
- 2) Drain and blow-out piping, tubing, headers, hoses, valve stacks and manifolds with clean dry air.
- 3) Drain pumps, accumulators, hydraulic motors and cylinders to insure removal of all fluids.
- 4) Dismantle, wash and clean strainers.
- 5) Drain & clean filter housings. Determine filter element compatibility with the Synxtreme FRH1-46 fluid and replace or clean as necessary.
- 6) Thoroughly drain and clean coolers.
- 7) Close the system and circulate a small amount of Lubriplate Hydro Flush fluid at low pressure.
- 8) Thoroughly drain the system and if possible run crackle test. If test estimates higher than .05-.10% moisture, then repeat step 7.
- 9) Thoroughly drain system (repeating Steps 1-6 above) and refill promptly with new Synxtreme FRH1-46 fluid.
- 10) After system is in operation, inspect carefully for leakage during the next two to three weeks.



FISKE BROTHERS REFINING COMPANY d/b/a LUBRIPLATE LUBRICANTS COMPANY

Manufacturers of Lubricants for the Industrial, Food, Beverage, Pharmaceutical, Automotive and Marine Industries since 1870



Corporate Headquarters: 129 Lockwood Street / Newark, NJ 07105 / Tel: 973-589-9150 / Fax: 973-589-4432

Midwest Office and Plant: 1500 Oakdale Avenue / Toledo, OH 43605 / Tel: 419-691-2491 / Fax: 419-693-3806

www.lubriplate.com / E-Mail: LubeXpert@lubriplate.com



ISO 21469 Certified