



ISO-9001 Registered Quality System.
ISO-21469 Compliant.

Sales, Service & Distribution Center
Newark, NJ 07105
Phone: 973-589-9150 Fax: 973-589-4432

Manufacturing, Sales, Service & Distribution Center
Toledo, OH 43605
Phone: 419-691-2491 Fax: 419-693-3806

Sales and Tech Service Support
Phone: 1-800-733-4755

LUBRIPLATE Synflush FG

*NSF H-1 Registered

“Halal & OU Kosher Pareve - Pending”

LUBRIPLATE Synflush FG is a unique, modern technology product designed to clean systems where a switch from an H-2 to an NSF H-1 Registered product is required. Costly downtime can be avoided as the **LUBRIPLATE Synflush FG** cleans internally without unit tear down. **LUBRIPLATE Synflush FG** is manufactured with ingredients that comply with FDA 21 CFR 178.3570.

LUBRIPLATE Synflush FG is compatible with Synthetic Polyalphaolefin, Polyolesters, Di-esters, Polyalkylene Glycols (PAG's) as well as mineral based fluids; therefore, it may be used when switching from many types of fluids without leaving behind incompatible residue.

Prior to using **LUBRIPLATE Synflush FG**, it is highly recommended, although not necessary, that a 4-ounce sample from the unit in question be submitted so that baseline testing may be performed. These test results will help to determine the effectiveness of the flushing procedures with subsequent oil samples.

Typical Physical Properties

Kinematic Viscosity @ 40°C; cSt	38 - 50
Pour Point	- 45°C
Flash Point; COC	218°C/425°F
Specific Gravity @ 20°C	0.95
Density (Lbs./Gallons)	7.935
Color	L0.5

Packaging

Part Number

55-Gallon Drum	L0961-062
5-Gallon Pail	L0961-060
Carton 12/1 Plastic Quarts	L0961-054

***NSF H-1 Registration No. - 143394**
(Meets USDA 1998 Guidelines)

*Authorized by NSF (National Sanitation Foundation) for use in food processing facilities as a lubricant or anti-rust agent on equipment in which there may be incidental contact involving the lubricated part and the edible product.

Manufactured with ingredients that comply with FDA 21 CFR 178.3570

"The **LUBRIPLATE Synflush FG** contains no components derived from TSE/BSE relevant animal species; therefore, it is compliant with the requirements of the TSE Note for Guidance EMEA/410/01 Rev. 2, October 2003".

(Over for Flushing Procedures)

Flushing Procedure for Food Grade Lubricants:

The following procedure may be followed to flush used oils from compressors and gear boxes.

1. Drain all used lubricant from the lowest points while unit is still warm.
2. Measure approximate volume of the lubricant drained.
3. Fill the sump with the equivalent amount of Lubriplate Synflush FG flushing lubricant.
4. Run the unit at standard operating temperature for 2 to 48 hours depending on need.
5. While the unit is still warm drain as much as possible flushing fluid from the unit.
6. Change oil filters according to OEM recommendations.
7. Fill the unit with the appropriate Lubriplate Food Grade Lubricant.
8. Draw sample from the sump after 500 hours for oil analysis.
9. Dispose of used oil properly according to state and local laws and regulations.

